

Pavement Decal Installation Instructions

1. Remove loose debris from designated area. The surface should be clean, dry and oil-free. Surface temperature must be above 50°F for best adhesion.
2. Mark the perimeter of the application surface with a chalk-line or other temporary marking.
3. Starting at top left corner, peel 6 to 8" of the back liner away from the decal.
4. Position the graphic using your temporary guides and apply exposed corner to surface.
 - 4a. Gradually peel back the remaining liner while simultaneously applying the rest of the decal. Press and smooth out decal as it is being applied to surface.
5. Starting in the center and working towards the edges; use a roller or your hand to thoroughly press the graphic onto the surface. Ensure the edges are sealed and that pavement decal fully adheres to any cracks or textures.

